Hoplites Military Solutions LLC

ASSEMBLY GUIDE

STEP BY STEP INSTRUCTIONS

1 POSITION BOTH ROLLS IN THE MIDDLE

Bring both halves of the X-TIC lane to the center of your setup area and position them side by side, aligned in the middle.

2 CONNECT AT THE CENTER SEAM

Align the edges and connect the two lane halves at the center se am using the Velcro over the metal plate to keep the lane together.

3 ROLL OUTWARD FROM THE CENTER

After the center seam is connected with the metal plate, roll both halves outward from the center toward each end, keeping the lane straight.

4 COMPLETE

Your X-TIC lane is now fully assembled and ready to use!